



USER MANUAL



★ ★ ★ ★ ★
Hebe
—TITAN-II—



1. Plug the charging adapter into a wall socket (5V 1A) and the other end of the cable into the charging port of the unit.
2. LCD lights up When the system is charging, when charge is complete the LCD turns off automatically.

CLEANING



- 
1. Fully charge the unit.
 2. Press the mouthpiece from one side to another to release it and expose the heating chamber.
 3. Grind herbs and place inside heating chamber.
 4. Do not overfill or pack too tightly.
- 

- 1 . Turn On/Off: Press button five times to turn on/off, when the system does not heating within one minute. it will be turned off automatically.
- 2 . Temperature Display: LCD shows the temperature of heating-bowl when system is turned on, shows the set temperature when adjusting temperature, and switch to the temperature of heating-bowl after two seconds.
3. Set the Temperature: The temperature range is from 200°F to 428°F adjustable, press + button to increase the temperature and press the - button to decrease it.
4. Heating: Press the button for three seconds, LCD is turned on and system start heating, when the temperature of heating-bowl reaches the set temperature, the system enters insulation state. Press button

For three seconds to turn off the LCD and stop heating when the system is in heating state.

5. Power Indication: Battery symbol at the bottom right of the LCD shows the remaining power.

6. Charging: Connect to the charger, the battery symbol shows charging state with dynamic indication and stops when charging is complete.

7. Celsius/Fahrenheit Switch: Press Switch Key and + Key to enter the Fahrenheit Mode, press the Switch Key and - Key to enter Celsius Mode.

8. Low Voltage Protection: When the battery is low, the system will stop heating and LCD backlight flashes.

OPERATING INSTRUCTIONS



CHARGING

DEVICE PARTS

- ① Mouthpiece
- ② Air Intake Vents
- ③ Switch Key
- ④ Function Control Key
- ⑤ Temperature Adjusting Key
- ⑥ LED Screen
- ⑦ Charging Jack



Push the mouthpiece
along the direction of arrow.



REMOVING MOUTHPIECE

1. Use the cleaning brush included with your kit to sweep and clean material from the chamber.
2. Unscrew the mesh filter from the mouthpiece and clean or replace as needed.
3. You may also use a small amount of rubbing alcohol with a q-tip or cloth to clean out the chamber.
4. Do not use cleaning solutions.

TIPS

1. A slow and steady inhale will produce the best results.
 2. Do not overfill or pack your herbs too tightly. This will restrict airflow and could reduce vapor.
 3. For thicker vapor, try raising the temperature. For smoother vapor, try reducing the temperature.
-